


EXPLODED VIEW  
MODEL BH221



## BH221 Parts List

Ref. No.	Part No.	Part Name	Qty
1	MIKTB101B1	Valve Body	1
2	MIKTC102A1	Front End	1
3	MIKTD103C0	Cylinder	1
4	MIKTD104A0	Piston	1
5	MIKTD105A01	Shell	1
6	MIKTE106B1	Diaphragm w/ Metal Sheet	1
7	MIKTE107A0	Lid	1
8	MIKTE108A1	Cap	1
9	MORTE110A0	Control Valve	1
10	MIKTE110A1	Valve Guide	1
11	MIKTE111A1	Valve Rod	1
12	MIKTE112A1	Control Lever	1
13	MIKTE113B0	Inner Tube	1
14	MIKTE114A0	Stud Bolt	2
15	MIKTE115A1	Nut (M18)	2
16	MIKTE116A0	Chisel Bushing 1"x4-1/4"	1
17	MIKTE117A0	Name Seal	1
18	MIKTE118A0	Spring	1
19	MIKTE119A1	Handle Grip	2
20	1110-410-01B	Latch	1
21	1110-410-01	Lock Spring	1
22	1120-413	Cap Bolt	1
23	UP-355456	U-Cup Packing	1
24	DS-355435565	Dust Seal	1
25	OBP-5	Back-up Ring	1
26	OBG-75	Back-up Ring	1
27	OP-5	O-ring	1
28	OP-14	O-ring	1
29	OC-0621	O-ring	1
30	OG-75	O-ring	2
31	WS-06	Seal Washer	1
32	WS-18	Seal Washer	2

Ref. No.	Part No.	Part Name	Q'ty
33	PS--1	Plug	6
34	PS-02	Plug	1
35	PR-6x20	Pin	1
36	PR-5x36	Pin	1
37	PR-10x60	Pin	1
38	PR-16x60	Pin	1
39	WF-18	Washer	2
40	HH-0630	High Pressure Hose	1
41	LH-0645	Low Pressure Hose	1
46	QB-5/16	Steel Ball	1
47	CR-12x18	Roller	1
48	Bh-12x50	Bolt	2
49	WS-12	Washer	2