

PARTS LIST MODEL OH-1

No.	CODE	DESCRIPTION	Q'ty	No.	CODE	DESCRIPTION	Q'ty
1	0310-001	Handle	1	15	BH-630	Bolt, hex socket M6x30	1
2	0310-002	Control Lever	1	17	BH-865	Bolt, hex socket M8x65	4
3	0310-003	Link	1	18	B-1025	Bolt, hex M10x25	2
4	0310-004	Stud bolt	2	19	AD100906	Connector,male1009-06	2
5	0310-005	Holder, hose	1	20	PS-212	Pin 2x12	1
6	0310-006	Adaptor	1	21	PS-315	Pin 3.2x15	2
7	0310-007	Pad	1	22	HH-0365<<<<AH01	High pressurehose,3/8",650L	2
8	WS-06	Spring washer(6)	2	23	OP-1513	O-ring W-1513 #112	2
9	WS-10	Spring washer(10)	4	24	QC-03M	Coupler male(3HP)	1
10	WP-08	Washer(8)	1	25	QC-03F	Coupler Female(3HS)	1
11	WP-10	Washer(10)	4	26	TFD3-03	Change valve	1
12	N6	Hex nut(M6)	1	27	ORB-S070	Motor, hydraulic	1
13	N-10	Hex nut(M10)	2	28	FC-03	Control valve, oil flow	1
14	BH-615	Bolt, hex socket M6x15	1				

EXPLODED VIEW MODEL OH-1

