

**PREVENT TROUBLES!**

**Check the power of**  
· **Breakers**  
· **Pile Drivers**

**Any Hydraulic, Electric,  
Pneumatic tools!**

**Under the power of 50-100N/m**

**JUST IN 10 SEC.**

**Power  
Checker  
PGH-110**



**Oil Temperature Controller**

Check the power correctly  
even in cold climate.



## How do you check the power?

For example, we used to stick a chisel into a big tire, and checked the power by feeling.

## What kind of equipment is available to check?

- **Maruzen Breakers & Pile Drivers**  
BH23K • BH161 • BH112  
KH240V • KH192 • KH183
- **Other Equipment**  
Any hydraulic, electric, pneumatic equipment of which impact power is 50-100N/m.




Handheld Breaker  
BH23K



Pile Driver  
KH192

## Simple and easy to maintenance



### Oil Pressure Indication

Check the impact power on scale of Oil Pressure Indication.

### Control Valve

Set the equipment on the device, and just turn the Control Valve!

### Cylinder of Hammering

Set the adapter on the device, and insert the equipment you want to check.  
Ready to check the power!

MARUZEN KOGYO CO., LTD.

155-8 Nagabuse Mishima-shi,  
Shizuoka-ken, 411-0824, Japan

TEL: 81-55-977-2140

FAX: 81-55-977-2184

[www.maruzenkogyo.co.jp/](http://www.maruzenkogyo.co.jp/)  
[overseas@maruzenkogyo.co.jp](mailto:overseas@maruzenkogyo.co.jp)