


EXPLODED VIEW MODEL KH800



PARTS LIST

No.	Part No.	Part Name	Q'ty	No.	Part No.	Part Name	Q'ty
*1	MIKTE108A	Cap Nut	1	22	AJ-1036-08	Adaptor	2
2	OS-22.4	O-Ring	1	23	21122-6-140SX	HOSE	2
3	1120-413-A	Cap Bolt	1	24		Coupler	1
*4	WS-06((((((((BH	Seal Washer	1	25		Coupler	1
5	MB13Z009A	Lid	1	26	OG-95	O-Ring	1
6	1110-421	Diaphragm	1	*27	MB13Z004A	Cylinder	1
7	1110-310-01	Shell	1	28	BPH1-PT3/8	Taper Plug	3
8	BH-12x70	Bolt, Hex Socket	4	29	PR-10*25	Spring Pin	1
9	OBG-50	Back Up Ring	1	30	MB850-040	Expander	2
10	OG-50	O-Ring	1	31	IUIS-50-60-6	U-Cup Packing	1
*11	MB13X001A	Valve Body	1	32	DS-5058565	Dust Seal	1
12	BPH1-PT1/8	Taper Plug	2	33	MB13X002A	Front Cap	1
13	MB06E007A MB13Z018A	Orifice Plug (ϕ 3.6/4.0)	1	34	WF-18-2L(JIL B 1252)	Washer	4
*14	MB13Z006A	Valve Bush	1	35	MIKTE115A	Nut	4
15	MB13Z008A	Control Valve	1	36	M8FTZ050A	Retainer Pin K	1
16	BPH1-PT1/8	Taper Plug	3	37	ϕ 6		
17	M1HTF107A	Spring (P)	1	*38	MB13A011A	Bush(A)	1
18	QB-5/16	Steel Ball	1	*39	MB13Z012A	Bush(C)	1
*19	MB13Z007A	Inner Tube	1	40	A-PT1/8 H	Grease Nipple	1
20	MB13Y005A	Piston	1	41	MB41X008A	Bracket A	1
21	MB13Z010A	Stud Bolt	4	42	MB41Z001B	Handle	2

PARTS LIST

No.	Part No.	Part Name	Q'ty	No.	Part No.	Part Name	Q'ty
43	MB41Z005B	Washer	8	64	MB14Z014A	Hook Wire	2
44	WF-14 2L JIS B 1252	Washer	4	65	MB41Z012A	Washer B	2
45	B-14x45 (10.9 T)	Bolt	4	66	BH12x25	Bolt	2
46	MB41Z004A	Guide	1				
47	B-12x30 (10.9 T)	Bolt	2		T6007	Push Rod Jig for Retainer Pin	1
48	WF-12H JIS B2760	Washer	3				
49	MB41X009B	Bracket B	1				
50	B-20x200	Bolt	3				
51	WF-20 (1-L)	Washer	6				
52	N1-20	Nut	3				
53	C-30B	Line Grip					
54	N-2072-06	Adaptor	1				
55	MB41Z007A	Base	1				
56	NB-5	Cap Nut	2				
57	N-2090-06	Adaptor	2				
58	B-5x40	Bolt	2				
59	WS-5	Washer	2				
60	HV-03-NO2	Selector Valve Assy	1				
61	MB41Z011A	Rod	1				
62	MB41Z015A	Driving Tool F (Flat)	1				
63	MB41Z012A	Washer A	2				

Assy supplied Parts

NO.	PARTS NUMBER	DESCRIPTION	Q'TY	COMPONENTS NO.
A1	MB24Z508A	Cap nut Assy	1	1, 2
A2	MB24Z509A	Cap bolt Assy	1	3, 4
A3	MB13Z501A	Accumulator Assy	1	1, 2, 3, 4, 5, 6
A4	MB13Z505A	Valve body Assy	1	11, 12(2), 13, 14
A5	MB13Z503A	Inner tube Assy	1	16, 17, 18, 19
A6	MB13Z502A	Cylinder Assy	1	16(2), 26, 27, 28(3), 30(2)
A7	MB13Z504A	Front end Assy	1	33, 38, 39, 40
A8	MB13Z039A	Seal Kit Assy	1	2, 4, 9, 10, 26, 31, 32